


IKEA NYBAKAD PLAY KITCHEN HACK



The materials needed for the project:

- IKEA Nybakad play kitchen
- Soap dispenser
- Wallpaper/ wrapping paper
- Scissors/ cutter
- Knobs (3 pcs)
- Decorative self-adhesive film (wood pattern)
- Colored tape



Install the knobs instead of the green ones provided with the play kitchen.



Cut the wrapping paper/wallpaper and glue it to the background panels. I used some tape to make it easy to remove if I'll want to change it in the future.



Using the decorative tape – mine matches the color of the wallpaper and soap dispenser – cover the black handle before attaching it to the panel.



Place the top panel (the one with the sink space) over the self-adhesive paper to get measures before cutting it. Leave 5/6 cm from the border, it will be enough to wrap it over the panel.

Once cut, attach the paper to the panel.



Using scissors or a cutter, cut out the paper part that covers the sink hole.

I decided to keep the tap hole covered as I didn't install the tap – I instead added the soap dispenser as a real water source.



Proceed with assembling the play kitchen and add any final touch that looks good to you!